


Diagnostic Connector Locations

<p>Peugeot</p>	<p>The vehicle's diagnostic connector (J1962 16-pin) can be found in the following locations:</p> <p>106 (1997 on): - Under dashboard - passenger side.</p> <p>206, 306, 806, Partner (1997 on): - Under dashboard - driver's side.</p> <p>307 (to 2004), 406 (1997 to 2000), 807: - Fascia fuse box.</p> <p>107: - To left of steering column.</p> <p>307 (2004 on): - Behind ashtray in centre console.</p> <p>406 (2000 on): - Driver's side dashboard (remove small plastic cover).</p> <p>407, 607: - Centre console compartment.</p> <p>The vehicle's diagnostic connector (2-pin) can be found in the following locations:</p> <p>106 (to 1996): - Engine compartment - under ECU.</p> <p>205, 306, 309, 605: - Engine compartment - near battery.</p> <p>205, 309, Boxer: - Engine compartment - near suspension turret.</p> <p>405: - Engine compartment - in relay box.</p> <p>The vehicle's diagnostic connector (30-pin) can be found in the following locations:</p> <p>106 (to 1997): - Passenger side - below dash.</p> <p>806, Partner (to 1997): - Driver's side - below dashboard.</p> <p>406 (to 1997), 605: - Fascia fuse box.</p>	<p>30-pin connector or 2-pin connector J1962</p>	 <p>OM10977</p> <p>OM1077</p> <p>OM1038</p>
-----------------------	--	--	---