



## **Service Light Reset – Peugeot 206 (1998 on)**

Using button located beneath the speedometer dial.

- Switch the ignition off.
- Press and hold button.
- Switch on the ignition.
- Keep the button depressed for 10 seconds.
- The “spanner” symbol will go out and the display read 0.